Tri-State Truck & Tractor Pullers RULES FOR 2022

General Rules

Membership will be **\$200.00** per vehicle (tractor or truck) and **one** driver if paid before May 1st. After May 1st membership \$250.00. Additional driver fee \$25.00 per driver.

insurance. Entry fee: Members \$20.00 per hook and non-members \$100.00 hook fee per event.

With membership of the vehicle you receive 2 pit passes, each additional driver will receive

1 pit pass with a max to any vehicle of 4 pit passes. No points awarded until membership is paid. All drivers must be at least 16 years of age and have a valid driver's licenses.

- 1. Each puller will be allowed two attempts to make a measurable pull within 100 feet. Moving the sled a measurable distance (one inch or farther) is an attempt. If vehicle breaks within 100 feet you may drop to last. You then have one attempt to move sled. On his/her first attempt, if competitor lets off on the throttle before going 100 feet, said competitor will get a second attempt, even if he went beyond the 100 foot mark. If no attempt is made to let off the throttle, no second attempt will be granted. Note: Intent is for driver not to slam on brakes to stop before 100 foot mark (or at any time), but to come to a smooth, safe stop.
- **2.** All vehicles are subject to random inspection during the season.
- 3. On option hook: Puller may take his first hook; he may rehook immediately or drop to last position in class. Puller must notify official before leaving the track.
- **4.** Helmets and fire jackets must be worn in all classes. <u>Helmet strapped</u> and fire jacket zipped while on the track. 1st time warning. 2nd time DQ. 1 warning per year. Helmet with rating of snell 90 or better, fire pants and gloves in all classes required.
- 5. All trucks and tractors are required to carry a working 2 ½# fire extinguisher at all times.
- **6.** No shorts allowed during pulling or while working as an official.
- 7. Whatever the weight class is set at, that's what the weight is. You can weigh less but not more.
- **8.** No cast iron flywheels
- **9.** No clamp on hubs, all tractors must have steel weld on hubs. (With the exception of the cockshut and Massey solid one-piece hubs in the V-8 class only).
- **10.** All diesel style vehicles shall have: Air shut off, operable from the rear of the tractor and operable from the driver's seat
- 11. All ignition style vehicles shall have shut off for ignition and a shut off for electric fuel pump(s) with kill switch operable from the rear of the tractor and operable from the driver's seat
- **12.** Floating finish to be decided by track official at each pull.
- **13.** Tri-State rules apply—if ever caught being illegal all points are taken away and the vehicle and driver are banned for 3 consecutive pulls. Caught a 2nd time vehicle is banned for 1 year and 10 days. Being illegal is anything that is a performance violation.
- **14.** Puller can enter only one class that they are eligible for. May hook twice if a 2-hook show for that class. One hook show entry in one class only that they are eligible for.
- **15.** Before any money or points are awarded the board will decide all controversies.
- **16.** When vehicle motor is running someone must be in the driver's seat at all times in the pits or on the track.
- **17.** Grounds for disqualification: losing safety equipment off vehicle, unsportsmanlike conduct either by competitor or member of his crew, losing weights, or out of bounds.
- **18.** No entry fee money is given back after the class has started.
- 19. All tractors must have wide front end.
- 20. All vehicles (truck or tractor) must have a working white back up light.
- **21.** The appearance of all vehicles should be physically presentable, and also in good mechanical condition to uphold the Tri-States Truck & Tractor Pullers reputation.
- **22.** New Procedure for scaling. **NO** scaling before the previous class is all scaled. No pre-scaling within ½ hour before pull starts.
- **23.** No riders of any age shall be allowed on a vehicle when it is being towed or driven. No rider on any vehicle in pit, track, or adjacent areas. This includes tow tractors or competing vehicles.
- **24.** No vehicle allowed to start in gear. Must have a working neutral start switch.

- **25.** The decision of the track official shall be final.
- **26.** Spillage on track will be judge's discretion. One warning to be given. Breakage not included. Recommend catch can for blowby.
- **27.** Flagmen: 1. sled green light. 2. 2nd finish line flagman green flag. 3. 1st start line flagman green flag. No attempting to pull until 1st flagman is green.
- **28.** Starting flagman shall be responsible for readiness of track, pulling vehicle and competitor.
- **29.** Second flagman shall be responsible for balance of course.
- **30.** The flagmen shall work for an entire class to assure consistent and equal treatment for all competitors in the class.
- **31. Drivers meeting 30 minutes before pull starts.** Prize money will be handed out at the next pull.
- **32.** Seat belt or 5 point harness required to be used in all pulling vehicles. If roll cage is used 5-point harness required.
- **33.** Alcohol or drug use is not condoned at Tri-State Truck & Tractor pullers events.
- **34.** With scale problems, use of certified count of weights will be used. (For emergency situation only with board approval).
- **35.** To have voting rights on rules you must have a paid vehicle membership and pull at two (2) Tri-State events. If you were a 2021 paid member and you hook one time in 2022 and break you retain voting rights for 2022.
- **36.** Any verbal warnings will be keep track of at the secretary's desk.
- **37.** Competitor must pull at position drawn within three minutes of time sled is ready. Delay will mean disqualification. If track official is notified prior to competitor's time slot, he will drop the competitor's position. This will constitute one of his two attempts. A competitor may do this only once per class. The last competitor in class also only has 3 minutes to hook and make an attempt. If you drop from breakage you are last in class
- **38.** The sled will be propelled down the track with the weight box moving up at least three times at the beginning of each event to condition the track.
- **39.** Any competitor or crew member attempting to sway the decision of any official by talking to the official, sled operator, or the promoter, is subject to disqualification from that class.
- **40.** When unscheduled or unsanctioned classes or events are added to those already scheduled, the scheduled classes will start on time.
- **41.** All pulls must start with a tight chain.
- **42.** Jerking on the chain to cause slack in the chain will be grounds for disqualification.
- **43.** Each competitor has the privilege of, and the responsibility for, spotting the sled for both of his attempts.
- **44.** Pull back tractor operator/sled operator must be notified of where competitor wishes sled placed.
- **45.** Use of crew members is recommended to expedite the show.
- **46.** No official pull may be started beyond the starting line, or behind the starting line. All sleds must be started in gear and with front of sled pan even with starting line.
- **47.** Sled pan must be within boundary lines at start of pull, with chalk line to constitute track boundary.
- **48.** If a vehicle is legal when hooked to the sled and breakage occurs while under the green flag, the pull will be measured.
- **49.** When disqualified in a class less than full, a competitor will receive 3 hook points and purse for last place.
- **50.** If more than one competitor is disqualified in a class less than full, all those disqualified will split the last place points and purse evenly.
- **51.** Any vehicle that hooks to the sled and makes a measurable pull shall be considered to have made an official hook even if the sled is reset and the vehicle cannot hook.
- **52.** Pulling vehicle must be able to drive onto the track and back up to the sled at the starting line, unhook, and drive off the track on their own power, unless breakage occurs while under the green flag.
- **53.** Class Restart: If the class is restarted, competitors having pulled previously have the following options: May hook immediately or may drop to last. It is the competitor's responsibility to alert the track official of his/her decision.

- **54.** If the first five vehicles in a class make a full pull, the class will automatically be started over except that a class cannot be restarted due to sled setting, if one-half of the class has already hooked. On any re-pull caused by a contest malfunction, the competitor may either re-hook immediately or drop to last.
- **55.** All decisions on re-pulls must be made before the vehicle leaves the track.
- **56.** Any disqualification on the first attempt bars a second attempt unless the class is restarted.
- **57.** Test Puller and Options: The competitor pulling in first position as determined by draw at time of entry is considered the test puller. He may take his first pull, provided the weight transfer is deemed right, he may immediately take his second pull or he may drop and pull in last position.
- **58.** Only the test puller and only on his first attempt will he/she not be disqualified or measured for running out of bounds. All other reasons for disqualification apply. On all subsequent attempts the "running out of bounds" disqualification rule will apply.
- **59.** If the weight transfer needs further adjustments, the competitor immediately following each adjustment will be considered "the test puller."
- **60.** Secondary hitch needs to be covered.
- **61.** To be awarded points you must be a paid member and have Tri-State decal on your vehicle after 2 pulls of becoming a member.
- **62.** All belts & rotating devices must be covered. (Except tires).
- 63. Registration closes $\frac{1}{2}$ hour before the pull starts. Late registration fee is \$40.00 per hook. May call ahead for registration if going to be late and your numbers will be drawn for you.
- **64.** Skies are required on all tractors. One warning to get them on.
- **65.** If class is not 100% completed and / or is cancelled due to weather or mechanical problems on the sled, no points or money is awarded to that class except show up points to registered pullers.
- **66.** End of track spotter must clear track before end flagman shows green flag. No one allowed on track while green flag is shown. End of track goes to infinity.
- **67.** No fuel tanks allowed in driver's compartment.
- **68.** If more than 50% of eligible voters are not present at the rules meeting for a particular class a member can ask for a ballot vote on a rule change for that class.
- **69.** The board of directors (6 members) and (1) tech person have final decision on all rule changes for the betterment of the club.
- **70.** A completed W-9 form is required from all persons receiving checks from Tri-State Truck & Tractor Pullers.
- **71.** Scratching and points. Scratch 3pts entry fee back, bump sled last place points and money, no entry fee back, no bump and no refund of entry fee last place points only.
- **72.** Anyone under 21 years of age must present valid driver's license before being able to register at an event or any person if age is questioned.
- **73.** All tractor classes will follow NTPA safety rules apply.
- **74.** To be included in any loyalty payout you must be a Tri-State member, have a Tri-State decal on your vehicle, attend a certain % of the pulls (to be determined) and get a sponsorship for the 2022 season.
- **75.** Each class is asked to sign up and sell Tri-State's promotional items at a certain number of Events.
- **76.** All inline turbocharged engines are required to have a cable(s) placed between first and second cylinder through exhaust manifold port area. Cable must be a minimum of one (1) 3/8 manufactured pendant line with a rating of at least 3000 lb. or more with a tag from the manufacture that indicates rated load capacity with swaged sockets.
- **77.** Or
- **78.** Two (2) 3/8" cables with a minimum of 4 clamps at the splice or crimps with a coupler on each cable. Cable(s) must circle the entire head /block assembly with a maximum of 4" slack.